

Modified Sine Wave Inverter USER MANUAL

DC-AC Power Inverter



Special Feature:

- Fuse: Built-out
- USB:5V,500mA
- Modified sine wave output
- High reliability and high efficiency
- High load ability
- Temperature and Load Controlled Cooling Fan
- Protection: Overload, Short Circuit, Reverse Polarity, Over/Under Input Voltage, Over Temperature.
- LED indicator light indicate Inverter, Fault mode.
- CE and RoHS Approved.

Thank you for purchasing ours Power Inverter. Please carefully read, understand and comply with all instructions before use.

Table of contents

1. Introduction.....	3
1.1 What’s an inverter.....	3
1.2 Select the right waveform.....	3
2. Main Components.....	3
2.1 Front panel.....	3
2.2 Rear panel.....	4
3. How to Use Inverter.....	5
3.1 Placement of the inverter.....	5
3.2 Mounting position of the inverter.....	6
3.3 Getting Connected.....	6
4. Important Safety Instructions.....	7
5. Protection Feature.....	8
6. Troubleshooting Reference.....	8
7. Specifications.....	9
8. Maintenance.....	9
9. Warranty.....	9
<u>Appendix I: Recommend.....</u>	10
<u>Appendix I I: Battery Wiring Examples.....</u>	11


Notice that specifications and product functionality may change without notice.

1. INTRODUCTION

1.1 What is an Inverter?

Power inverter is an electronic device that converts low voltage DC(Direct Current) electricity from a battery or other power source to 100V-120V or 220V-240V AC(Alternating Current) household power. DC is the power that is produced by battery or other power source while AC is the standard power needed to run electrical equipment. A power inverter does the opposite of a rectifier and is used in places and situations where AC power is not available.

1.2 Select the right waveform




Modified Sine Wave: If your equipment can accept some voltage fluctuation, consider a modified sine wave inverter. These inverters provide mobile power at a more affordable price and come in a full range of size-from handheld to high performance.

Do not use to power sensitive devices such as medical equipment or computers. Some audio equipment may perform poorly if run on Modified Sine Wave power.

2. MAIN COMPONENTS

2.1 Front Panel

The front panel view shows the inverter's ON/OFF Switch, AC Outlet, LED Indicator Light, Vent Outlet, USB



A. ON/OFF Switch.

This switch controls ON/OFF operation of the inverter.

B.LED Indicator Light

Two LED indicator light: Inverter, Fault.


a)Inverter: This light will illuminate continuously whenever connected equipment is receiving battery-supplied, inverted AC power.

b)Fault: Turns Red shows fault, reference to Troubleshooting.

C. AC Outlet.

Outlet sockets available: North America, Europe(schuko), UK, Australia, etc.

AC Output Optional:



D. Vent Outlet.

To decrease the temperature of the inverter.

E. USB Port:5V,500mA


Powers and charges USB-enabled devices.

G: Remote Switch Port(Optional):

Use to connect the remote ON/OFF switch via a communication cable.

2.2 Rear Panel

The rear panel view shows the inverter's Cooling fan, DC Battery Terminals, Fuse.



A. Cooling fans/ Ventilation Windows

The fans automatically operate when the internal temperature(exceeds 45°C) of the inverter requires cooling. Always allow free air flow – do not block the vents.

B. DC Battery Terminals

Connect the inverter to battery or other power sources.

Negative (-) and Positive (+) DC terminals should be kept insulated to protect from accidental short circuits.

- a) Connect the black cable to the black post marked (-) on the back of the inverter. Connect the other end to the negative terminal on the battery.
- b) Connect the red cable to the red post marked (+) on the back of the inverter.

Connect the other end to the positive terminal on the battery.


If you connect the cables to the incorrect terminals, you will reverse the polarity and damage the inverter.

! PROHIBITED REVERSE POLARITY.

DAMAGE CAUSED BY REVERSE POLARITY WILL NOT BE COVERED BY WARRANTY.

C. Fuse

Fuse was built-out is a very good design as you can very easy to change the fuse outside the inverter if your inverter fuse was blown.



3. HOW TO USE INVERTER

3.1 Placement of inverter

The location where to install inverter must be:

A. Dry: Do not allow water to drip or splash onto it.

B. Cool: Ambient air temperature should be between 0° C and 40° C - ideally between 15° C and 25°. Do not place the inverter on or near a heating vent or any piece of equipment which is generating heat above room temperature. Do not place the inverter in direct sunlight unnecessarily.

C. Ventilated: Allow at least one inch of clearance around the unit for air flow. Do not place items on or over the inverter during operation. Make sure that air is allowed to circulate freely around the unit. A fan is helpful in the case where the inverter is operating at maximum

D. Safe: Do not install the inverter in the same compartment as the batteries or in any compartment where flammable liquids or fumes may be or may become present.

E. Dust Do not install the inverter in a dusty environments. The dust can be inhaled into the unit when the cooling fan is working.

F. Close to batteries: Avoid excessive cable lengths. Do not install the inverter in the same compartment as batteries.

3.2 Mounting position of the inverter

The inverter may be mounted horizontally on the top of a horizontal surface or under a horizontal surface. The inverter may be mounted on a vertical surface only horizontally.

3.3 Getting Connected.

To get going, follow these easy steps.

1. Power supply selection - It must get power from storage battery/batteries or a car cigarette lighter port.

2. Connect inverter to power supply. Set the switches into the OFF position (including inverter and appliances).

a. Get power from battery/batteries: Connect the DC cables to the DC battery terminals on the rear panel of the inverter. The red terminal is positive (+) and the black terminal is negative (-).

b. Get power from car cigarette lighter port, insert the car cigarette lighter plug into the car cigarette lighter port.

3. Connect inverter to appliances. Make sure the load power within the rated power of inverter and the start power should not exceed the peak power of the inverter. When having the inverter connected with appliances and a power supply, switch on the inverter and appliances.

4. IMPORTANT SAFETY INSTRUCTIONS

Incorrect installation and misuse of the inverter may result in danger to the user or hazardous conditions.

1. Do not attempt to connect the any other power source, including any AC power source .
2. Make sure the opening to the ventilation fan and vent holes are not blocked.
3. Avoid pulling on the cords and cables. Always grip plugs firmly when unplugging from power source and when disconnecting cables.
4. To avoid electrical hazard, be sure to unplug the inverter from its external power source before inserting the AC plug.
5. For indoor use only. Avoid exposure to external heat sources; direct, prolonged sunlight; dust; corrosive chemicals; and moisture.
6. It is normal for inverters to become warm during use. Avoid touching the device during use. Avoid placing in direct sunlight or near heat-sensitive materials.
7. Do not drop or subject the inverter to undue shock.

8. Do not place anything on top of the inverter.
9. Always with the supplied cables and connectors as shown. Use of cables, connectors, or accessories not supplied with this product constitutes misuse and may result in injury or damage.
10. Do not attempt to service or disassemble. The unit is not user-serviceable. Attempting to disassemble or service the unit can result in electrical hazard, including death from exposure to high voltage. If you experience problems with the unit, discontinue use and Contact Technician.
11. When cleaning the inverter, please switch off power(unplug the inverter).Carefully clean with dry cloth. Do not use wet cloth or cleanser.
12. Disconnect all AC and DC side connections before working on any circuits associated with the inverter. Turning the ON/OFF switch on the inverter to off position may not entirely remove dangerous voltage.
13. Keep away from children.

5. PROTECTION FEATURE

Inverter is equipped with numerous protection features to ensure safe operation.

Input Low Voltage Protection

A: When battery voltage is below $10.5V \pm 0.5V$ (for 12V input inverter)/ $21V \pm 1.0V$ (for 24V input inverter)/ $42V \pm 2.0V$ (for 48V input inverter), a buzzer will alarm, which indicates DC power supply voltage is descending and batteries need to recharge.

B: When input voltage is below $10V \pm 0.5V$ (for 12V input inverter)/ $20V \pm 1.0V$ (for 24V input inverter)/ $40V \pm 2.0V$ (for 48V input inverter), AC output will be automatically shut off, a buzzer alarm and ALARM/WARNING light turns red at the same time.

Input Over Voltage Protection

When input voltage reach $15V \pm 0.5V$ (for 12V input inverter)/ $30V \pm 1.0V$ (for 24V input inverter)/ $60V \pm 2.0V$ (for 48V input inverter),ALARM/WARNING light turns red and the AC output will be shut off automatically.

Short Circuit Protection

When short circuits occur, output will be shut off and ALARM/WARNING light turns red.

Overload Protection

When overloads occur, output will be shut off and ALARM/WARNING light turns red.

Reverse polarity protection

When battery terminals are reverse connected, fuse will be burned to protect appliances.

Over Temperature Protection

When heat sink temperature exceeds $45^{\circ}C$, the inner cooling fan will automatically turn on to cool the inverter; when less than $30^{\circ}C$,the inner cooling fan will automatically shut off.

When inner temperature exceeds $70^{\circ}C$, AC output will automatically shut off, ALARM/WARNING light turns red. It is unusable for 15 minutes.

6.TROUBLESHOOTING REFERENCE

Acoustics buzzer alarms

When applying the inverter to acoustics devices, some inferior acoustics devices will buzz, this is because the output wave from the inverter is modified sine wave inverter.

TV Interference

You can get minimum interference through use of a filter. On some occasions, when the interference of every weak signals becomes too obvious, you can try the following:

- Place the inverter far from the TV and TV antenna.
- Try to change the direction of TV signals cable and TV antenna to reduce the interference to minimum.
- Use screen cable antenna of highly quality.

Problem: No output voltage

Possible Causes	Solution
Battery voltage too low	Recharge or replace the battery
Overload	Reduce the load
Inverter thermal protection	Cool the inverter and place it in the place with good ventilation; Reduce the load.
Inverter start-up fail	Repeat starting the inverter
Reverse polarity connection and fuse melted	Replace the fuse with a fuse of equivalent value.

Problem: Inverter no response

Possible Causes	Solution
Poor contact between battery and inverter	Reconnect them
Reverse polarity connection and fuse melted	Replace the fuse with a fuse of equivalent value.

Problem: Output voltage low

Possible Causes	Solution
Input voltage too low	Make sure input voltage is within the rated range.
Overload	Reduce the load

Problem: Low voltage alarm

Possible Causes	Solution
Battery no power	Recharge the battery
Battery voltage too low or poor connection	Recharge the battery, check terminals connection or clean terminal with a dry cloth

7.Specifications

Items		Models				
		TY-150-M	TY-300-M	TY-500-M	TY-600-M	TY-1000-M
Continuous power		150W	300W	500W	600W	1000W
Surge Power		300W	600W	1000W	1200W	2000W
Packing	PCS/CTN	16	16	16	16	6
	KGS/CTN	16.5	17	18	19	16
	Dimension(MM)	435*370*370	435*370*370	435*370*370	435*370*370	420*340*460
Items		Models				
		TY-1500-M	TY-2000-M	TY-2500-M	TY-3000-M	
Continuous power		1500W	2000W	2500W	3000W	
Surge Power		3000W	4000W	5000W	6000W	
Packing	PCS/CTN	2	2	2	2	
	KGS/CTN	10.5	12	14.5	15	
	Dimension(MM)	430*305*355	430*305*355	450*305*355	495*360*500	
Input voltage		12V / 24V/ 48V				
Output voltage		100~120VAC / 200~240VAC (Optional)				
Output Frequency		50Hz±0.1% or 60Hz±0.1% (Optional)				
Efficiency		>88%				
Output Waveform		50Hz±0.1% or 60Hz±0.1% (Optional)				
Protection		Low Voltage Alarm,Low Voltage Shut down, Over Voltage Shut down,Over temperature, Over load,Short circuit, Reverse Polarity				
Battery types		Open & sealed lead acid battery				

Note: *The specifications are subject to change without prior notice for further improvement of products.

8.Maintenance

To keep your inverter operating properly, there is very little maintenance required. You should clean the exterior periodically with a dry cloth to prevent accumulation of dust and dirt. At the same time, tighten the screws on the DC input terminals.

9.Warranty

We guarantee this product against defects in materials and workmanship for a period of one year from the date of retail purchase by end user.

This warranty will be considered void if the unit has been misused, altered, or accidentally damaged. We are not liable for anything that occurs as a result of the user's fault.

If the warranty period for your product has expired, if the unit was damaged by misuse or incorrect installation, if other conditions of the warranty have not been met, or if no dated proof of purchase is available, your unit may be serviced or replaced for a flat fee.

Appendix I: Recommend

For correct operation, the battery voltage should be between $0.9 \times V_{nom}$ and $1.29 \times V_{nom}$ where V_{nom} is 12V, 24V or 48V depending on model, and must be able to supply sufficient current to your inverter. The following table displays the recommended things (Battery Cables, Fuses, Battery Capacity) per inverter type.

Inverter Type	Input Voltage	DC Battery Cable	Fuse	Battery Capacity
150W	12V	2.5mm ² (1*red/1*black)	35A*1	≥ 25Ah
	24V	2.5mm ² (1*red/1*black)	20A*1	≥ 12Ah
	48V	2.5mm ² (1*red/1*black)	10A*1	≥ 10Ah
300W	12V	4mm ² (1*red/1*black)	35A*1	≥ 50Ah
	24V	2.5mm ² (1*red/1*black)	20A*1	≥ 25Ah
	48V	2.5mm ² (1*red/1*black)	10A*1	≥ 12Ah
500W	12V	6mm ² (1*red/1*black)	35A*4	≥ 100Ah
	24V	4mm ² (1*red/1*black)	20A*4	≥ 50Ah
	48V	2.5mm ² (1*red/1*black)	10A*4	≥ 25Ah
600W	12V	6mm ² (1*red/1*black)	35A*4	≥ 100Ah
	24V	4mm ² (1*red/1*black)	20A*4	≥ 50Ah
	48V	2.5mm ² (1*red/1*black)	10A*4	≥ 25Ah
1000W	12V	10mm ² (1*red/1*black)	35A*4	≥ 160Ah
	24V	6mm ² (1*red/1*black)	20A*4	≥ 80Ah
	48V	4mm ² (1*red/1*black)	10A*4	≥ 40Ah
1500W	12V	10mm ² (2*red/2*black)	35A*6	≥ 250Ah
	24V	6mm ² (2*red/2*black)	20A*6	≥ 125Ah
	48V	4mm ² (2*red/2*black)	10A*6	≥ 60Ah
2000W	12V	16mm ² (2*red/2*black)	35A*8	≥ 320Ah
	24V	10mm ² (2*red/2*black)	20A*8	≥ 160Ah
	48V	6mm ² (2*red/2*black)	10A*8	≥ 80Ah
2500W	12V	16mm ² (2*red/2*black)	35A*10	≥ 400Ah
	24V	10mm ² (2*red/2*black)	20A*10	≥ 200Ah
	48V	6mm ² (2*red/2*black)	10A*10	≥ 100Ah
3000W	12V	16mm ² (2*red/2*black)	35A*12	≥ 480Ah
	24V	10mm ² (2*red/2*black)	20A*12	≥ 240Ah
	48V	6mm ² (2*red/2*black)	10A*12	≥ 120Ah

Appendix I I : Battery Wiring Examples

In renewable energy systems, batteries are connected to each other in one of three ways:

- Series (voltage increases, amperage stays the same as a single battery)
- Parallel (voltage stays the same as a single battery, amperage increases)
- Series/Parallel (both voltage and amperage increase)

